



Exam Code: HP0-J15

Exam Name: HP StorageWorks MASE 2088 Delta Exam

Vendor: HP

Version: DEMO

Part: A

1: On an MSA2000, what is the pre-allocated reserve space for snapshot data?

- A.target volume
- B.reserve pool
- C.snap pool
- D.master volume

Correct Answers: C

2: What is the purpose of the Trust Virtual Disk?

- A.storage of meta-data for all disks in an array
- B.provide secure storage for data encryption keys
- C.disaster recovery for RAID set after power restoration
- D.quorum disk for more than 2-node Windows Cluster

Correct Answers: C

3: Which capabilities does the MSA2012fc provide?

- A.dual-ported SATA drives; support for up to 64 hosts
- B.support for up to 64 drives; ability to mix SAS and SATA drives in same drive enclosure
- C.snapshot/clone capability; ability to mix SAS and SATA drives in same drive enclosure
- D.controller-based replication capability; support for up to 64 drives

Correct Answers: C

4: A virtual disk has been quarantined. You attempt to dequarantine the virtual disk, but there are not enough drives available to maintain the selected RAID level. What happens?

- A.The virtual disk size is reduced to accommodate the RAID level.
- B.The virtual disk goes offline and its data cannot be recovered.
- C.The virtual disk stays in quarantine until disks are added.
- D.The virtual disk goes critical and the sparing routine is called.

Correct Answers: B

5: MPIO drivers are an important part of connecting Windows servers to storage. In which part of Windows are these drivers run?

- A.user mode
- B.realtime mode
- C.real mode
- D.kernel mode

Correct Answers: D

6: You are installing an MSA2012i array. The customer asks about the data protection features of the new array. How many volume copies can be created in this array?

- A.48
- B.64
- C.128

D.256

Correct Answers: C

7: You need to directly attach an MSA2000fc array to a host. Which SAN topology is supported?

- A.point-to-point
- B.cascade
- C.local mesh
- D.loop


Correct Answers: D

8: The MSA2012 controller can be accessed by two types of users: monitor and manage. What is the maximum number of monitor users that can be logged into an MSA2012 controller at any one time?


- A.2
- B.3
- C.4
- D.5

Correct Answers: D

9: Click the Task button. Click on the snap pool space in the color code area of the volume status information.



Correct Answers:



10: An MSA2012fc storage solution has just been installed. You try to manually add a global spare disk. The operation fails and you receive an error message. What is the most probable reason for the failure?

- A.No virtual disk exists on the system.
- B.Unassigned disks are automatically used as global spares.
- C.Global spare disks must reside in the same enclosure as the Vdisks.
- D.Four global spares have already been assigned.

Correct Answers: A