



Exam Code: 920-325

Exam Name: nncss-communication server 1000/4.0
software install-maint

Vendor: Nortel

Version: DEMO

Part: A

1: You have just tested a conference loop on a CS 1000 Rls. 4.0 system. To enable the loop you access LD 38 and enter the ENLX loop command. What does loop in the command line represent?

- A.the conference loop phone number
- B.the odd loop of the conference/TDS loop pair
- C.the conference loop common language identifier
- D.the conference loop physical pair connection point

Correct Answers: B

2: You need to test the continuity of the speech path to each and every Intelligent Peripheral Equipment (IPE) shelf on a CS 1000 Rls. 4.0 large system. When and how is this test invoked in LD 30?

- A.When: during the daily routines of the system
How: manually on the large system
- B.When: during the midnight routines of the system
How: automatically by the system
- C.When: during the midnight routines of the system
How: manually on the large system
- D.When: during the off peak hours of the system
How: create a script of the test command line and have it run on a timer

Correct Answers: B

3: A customer with a large CS 1000M Rls 4.0 system is performing a Backup and Restore using LD 43. To ensure the backup file will fit on a single floppy disk (or at most two), which command should be used?

- A.EDD
- B.ZIP
- C.OVLY
- D.PARM

Correct Answers: A

4: A service provider with a CS 1000 Rls. 4.0 system requires an Automatic Call Distribution (ACD) high-speed link to be disabled temporarily. Which overlay and command will accomplish this function?

- A.Access LD 32 and use the DISL command.
- B.Access LD 43 and use the EDD HSL command.
- C.Access LD 48 and use the DIS HSL command.
- D.Access LD 80 and use the DIS ACD command.

Correct Answers: C

5: A customer with a CS 1000 Rls. 4.0 system is experiencing intermittent issues with dropped calls on several Primary Rate Interface (PRI) trunks. They want to run a Call Trace using LD 80 to trace the calls through the PRI trunks. Which command will give them the required information?

- A.TRAD
- B.TRAC
- C.TRAT
- D.TRAO

Correct Answers: A

6: In a scenario where there are defective serial I/O ports within a CS 1000 Rls. 4.0 system, how is the state of each Serial Data Interface (SDI) port checked using overlays?

- A.LD 32 using the TEST IOP command
- B.LD 37 using the STAT TTY command
- C.LD 117 using the PRTSTAT command
- D.LD 135 using the DISL command

Correct Answers: B

7: A service provider with a CS 1000 Rls. 4.0 system is planning a late night work activity at a Call Center. Thus, they require that the Automatic Call Distribution (ACD) high-speed link be disabled. Which overlay and command will accomplish this function?

- A.LD 32 using the DISL command
- B.LD 43 using the EDD HSL command
- C.LD 48 using the DIS HSL command
- D.LD 80 using the DIS ACD command

Correct Answers: C

8: A service provider with a CS 1000 Rls. 4.0 system wants to configure the Embedded LAN (ELAN) local IP address for the Point-to-Point Protocol (PPP) interface (10BaseT) with IP address 142.68.33.1. Once LD 117 is accessed, which two commands can be used to configure this interface? (Choose two.)

- A.NEW HOST LOCAL_PPP 142.68.33.1
- B.NEW HOST REMOTE_PPP 142.68.33.1
- C.CHG IPM 0 142.68.33.1 255.255.255.0
- D.CHG LOCAL_PPP 0 142.68.33.1 255.255.255.0 YES

Correct Answers: A B

9: You must remove a FIJI card from a CS 1000 Rls. 4.0 system. Before the ring containing the card to be removed can be disabled, Auto-Recovery must also be disabled. Which overlay and command will accomplish this task?

- A.LD 32 using the DISR command
- B.LD 39 using the ARCV OFF command
- C.LD 117 using the DISA command
- D.LD 135 using the DIS RING command

Correct Answers: B

10: A customer with a Primary Rate Interface (PRI) circuit to a CS 1000 Rls. 4.0 system has just completed a lengthy work activity. Now they require that the D-channel be reset to restore their

circuit. Which overlay and command will accomplish this function?

- A.LD 32 using the DISD command
- B.LD 43 using the EDD DCH command
- C.LD 80 using the DIS PRI command
- D.LD 96 using the RST DCH command

Correct Answers: D